CAM Boot Instructions

STEP 1: Place foot in boot, make sure heel is all the way to the back.





*If your heel cannot fit all the way back, press the SMALL deflate button on the side to deflate the air pockets



STEP 2: Velcro ONLY the 4 grey pads over each other



STEP 3: Take the grey plastic piece and place it over the folded velcro pads





STEP 4: Take the straps and fold them over the top plastic piece



STEP 5: Press the LARGE button on the side IF NEEDED to add extra comfort, this will inflate air pockets all along the boot

